

28002 Assemble Instruction

Assemble Attention

1. Preparation must be done based on the 《Mechanism Assemble Instruction》
2. Assemble the mechanism according to the assembly sequences, during Step 1, Step 2, Step 3 the assemble holes must be accurate, the left and right parts are symmetrical.
3. When installing, pay attention to the strength of the tool to avoid the screw thread damaged by over strength, also need pay attention to self-tapping screws in correct direction; repaint the screw pan, and screw bottom and mechanism surface if the painting is damaged during installation.
4. Please check the 28002 BOM for all the materials needed.

Step 1

Hex Bolt 1/4"*38

Front Driving Square Tube

Antiskid Nut 1/4"

Step 3

268 Spring With Plastic, symmetric

Step 2

Antiskid Nut

Hex Bolt 1/4"*38

Rear Driving Square Tube

Note: When assemble, pay attention to the direction of the front driving tube , the sidde with extra holes in front

